

Setup your TV control using direct code entry

1. Press the TV **power** button.
2. Press and hold setup until the TV **power button** blinks twice.
3. Press and release the **TV key**. The TV key should stay lit.
4. Enter the first TV code for your brand from the code list.
5. Press the **power button** to test TV control. If the TV turns off, setup is complete.
6. If the TV does not turn off, repeat **Step 4** using the next code for your TV brand.

Troubleshooting

PROBLEM	SOLUTION
Mode key does not blink when a key is pressed.	Replace batteries.
All the keys on my remote do not light up.	Pres setup key two times to enable backlight.
Tried all codes for my brand of device and none work.	Visit urcsupport.com for model-based search.

TV Codes

Admiral	0093 0163 0363 0418 0087 0305 0264	Futurerech	0180	Nikko	0030 0092 0178
Aiko	0092 0009 0037 0556 0216 0371 0035 0433 0072	GE	0051 0343 1454 0047 0178 0135 0747 0021 0451 0174	Onwa	0180 0371 0602 0218 0433 0581 0102
Alaron	0179 0216	Gradiente	0053 0056 0170 0392 0037 0556	Optimus	0154 0250 0166 0650 1924
Amer. Action	0180	Hallmark	0178	Orion	0037 0179 0177 0236 0355 0463 0556 0235 0655 0714 0320 0321 0443
Anam	0003 0037 0556 0009 0700 0068 0628 0180 0250 0861	Harley Davidson	0179	Panasonic	0051 0650 0226 0108 0250 1924 0054 0037 0214 0556
Audiovox	0003 0092 0451 0180 0623	Harvard	0068 0180	Philco	0054 0087 0463 0774 0020 0074 0028 0418 0747 0145
Belcor	0019	Hitachi	0145 0225 0038 1225 0009 0056 0349 0016 0036 0151 0019 0356 0027 0044 0030 0150	Phillips	0037 0054 0556 0056 0238 0012 0721 0000 0554 0019 0191 0020 0087
Bell & Howell	0016 0017 0154	Hypersonic	0361	Pioneer	0038 0166 0866 0011 0037 0109 0170 0556 0163 0423
Bradford	0180	Infinity	0054	Portland	0019 0092 0374 1909
Brockwood	0019	Innova	0037	Quasar	0051 0247 0650 0165 0250 0009 0865
Broksonic	0003 0236 0463 1905	Inteq	0017	RCA	0000 0047 0018 0135 0019 0174 0030 0625 0038 0060
Candle	0030 0046 0056 0186	JBL	0054	Radio Shack	0019 0037 0030 0556 0032 0047 0056 0154 0165 0178
Carnivale	0030	JCB	0000	Realistic	0019 0030 0032 0056 0154 0165 0178
Carver	0054 0170	JVC	0653 0053 0036 0154 0190 0371 0508 0606 0683	Runco	0017 0030
Celebrity	0000	KEC	0180	Sampo	0030 0009 0032 0052 0036 0092 0093 0154 0171 0178
Casio	0037 0556 0163 0349 1904	Kenwood	0019 0030 0105	Samsung	0019 0618 0644 0056 0060 0587 0037 0178 0030 0556 0009 0702 0774 0093 0217 0448 0747 0482 0370 0264 0092 0451
Cineral	0092 0451	KTV	0030 0180 0217 0185 0280	Sansei	0092 0451
Citizen	0030 0092 0451 0046 0056 0060 0186 0180 0280	LG	0037 0056 0442 0001 0370 1178 0002 0009 0377 0032 0556 0003 0217 0019 0030	Sanyo	0154 0208 0157 0280 0484 0292 0721 0011 0036 0045 0370 0068 0339 0072 0216 0104 0217 0145 0146 0156 0178
Concerto	0056	Logik	0001 0011 0016 0033 0060 0698 0773 0009 0193 0264	Scotch	0019 0236 0178 0179 0180
CXC	0180	Luxman	0056 0579	Scott	0047 0146 0171 0054 0156 0747 0056 0154 0159 0178
Crosley	0054 0087 0074 0247 0163	LXI	0047 0054 1347 0154 0156 0178 0747	Sears	0047 0146 0171 0054 0156 0747 0056 0154 0159 0178
Crown	0009 0180 0712 0037 0370 0486 0556 0418 0487 0579	Magnavox	0020 0037 0054 0024 0556 0028 0030 0036 0179 0186	Semivox	0180
Curtis Mathes	0016 0047 0466 0030 0054 0060 0093 0145 0056 0154	Majestic	0016	Sharp	0093 0165 0009 0386 0030 1193 0032 0157 0036 0294 0491 0256 0653 0053 0193 0650
Dayton	0009	Marantz	0030 0037 0054 0556 0412 1154	Sony	0000 1505 1651 0011 1010 0036 0650 1100 1925 0102 0353 0111 0037 0080 0556 0157 0834
Denon	0145 0511	Matsushita	0250 0650	Supreme	0000
Contec	0009 0180 0216 0036 0185 0157 0011 0264 0037 0556	Megatron	0003 0145 0178	Sylvania	0020 0054 0186 0028 0030 0171 0381
Dumont	0017 0087 0019 0070 0104 0102 0217 0072 1904	Memorex	0009 0016 0056 1920 0154 0150 0178 0179 1037 0620	Symphonic	0171 0180 1904
Electroband	0000 0185	MGA	0019 0030 0150 0178 0037 0556 0218 0104	Toshiba	0035 0060 0009 0154 0508 0036 0156 0070 0093 0243 0145 0102 0227 1508 0217 0264 0109 0381
Craig	0180	Midland	0017 0032 0047 0051 0135 0747	Yamaha	0019 0650 0839 0030
Envision	0030	Motorola	0093		
Fisher	0104 0154 0217 0036 0159 0208 0370 0544 0555 0045 0087 0157 0361 0163 0303	MTC	0019 0030 0060 0370 0056 0349 0512 0163 0216 0361		
Fujitsu	0179 0206 0683 0072 0186 0102 0809 0853 0217 0163 0009 0037 0556 0361 0259				