Manually turn on the device that you want to setup on the remote (i.e. TV).

Press and hold the **TV** and **OK/SEL** buttons simultaneously for **3 seconds**. The LED light for the TV button will turn on, indicating it is ready to be programmed.



Big Button Remote Guide

Press and release the **CH+ or CH-** button one at a time, or keep it pressed. Release as soon as the TV shuts off.



Press the **TV button**, the TV LED should flash twice, indicating the code has been stored.



Press the **STB button** and verify operation.



